







SR 200

SYSTEMÖVERSIKT



Nr.	Benämning	Modellnummer	Best Nr.
1.	Helmask, PC-visir Helmask, glasvisir	SR 200 SR 200	H01-1212 H01-1312
2.	Fläkt	SR 500	H06-0112
3.	Fläkt	SR 500 EX	H06-2012
4.	Fläkt	SR 700	H06-7010
5.	Trycklufttillsats	SR 307	H03-1412
6.	Andnings slang, PU, 0,9 m Andnings slang, PU, 1,0 m Andnings slang, gummi, 0,7 m Andnings slang, gummi, 0,9 m	SR 550 SR 550 SR 551 SR 551	T01-1216 T01-1220 T01-1218 T01-1221
7.	Partikelfilter P3 R	SR 510	H02-1312
8.	Partikelfilter P3 R	SR 710	H02-1512
9.	Gasfilter A1 Gasfilter A2 Gasfilter AX Gasfilter ABE1 Gasfilter ABE2 Gasfilter K1 Gasfilter K2 Gasfilter ABEK1	SR 217 SR 218 SR 298 SR 315 SR 294 SR 316 SR 295 SR 297	H02-2512 H02-2012 H02-2412 H02-3212 H02-3312 H02-4213 H02-4312 H02-5312
10.	Gasfilter A2 Gasfilter ABE1 Gasfilter A1BE2K1	SR 518 SR 515 SR 597	H02-7012 H02-7112 H02-7212
11.	Kombinationsfilter ABEK1-Hg-P3 R	SR 299-2	H02-6512
12.	Kombinationsfilter A1BE2K1-Hg-P3 R	SR 599	H02-7312
13.	Slang	SR 360	H03-34XX
14.	Slang	SR 358	H03-30XX
15.	Slang	SR 359	H03-31XX
16.	Tryckluftfilter	SR 99-1	H03-2810